



1

Insert paper



2

Insert support
part



3

Twist support
part 90°



4

Insert Paterson
central column



2.1

Apply force to make
cylinder oval from top



3.1

Insert support
part

Note:

This reel is not
compatible
with staining
developers.

5 Now you are ready to insert the reel to
Paterson 5 reel tank and start developing
your paper or film with AGO Film Processor.

Minimum chemical consumption:

Multi-reel 5 tank	250ml
Multi-reel 8 tank	400ml