





**1.** Remove backdrop frame from carry bag and unfold top section upwards, and secure bracket into mount clip.



**2.** Starting with the lower legs, unlock each leg lock and expand leg section outwards to stabilize and level the frame. Repeat these steps to extend upper sections.



**3.** Unfold backdrop and hang corner grommets on hooks. Hang top 3 grommets first, then lower grommets.

**4.** Extend each frame section as needed to pull backdrop taut and remove any wrinkles. Adjust rear frame leg to ensure backdrop is upright and vertical. If using 5'x12' backdrop, sweep out and remove any wrinkles.