





We know looking at these amazing photographs gets you excited to start shooting, but please take your time and read the following instructions



Thank you for these 8x10 photos, Marco C. Krenn, Stefan Milev, Penny Felts-Nannini and Melodie McDaniel

**Film Storage** Best used within 12 months of production date. Store unopened film pack in the fridge at 5–10°C/41–50°F. Do not freeze! **Film Characteristics** The development of this film is a sensitive chemical reaction, triggered by light and affected by various parameters such as temperature, age, time, mechanical manipulation and others. Therefore variations in results are not only possible but to be expected with this analog instant film. **Limited Warranty** Any film that does not show any photographic result due to defective manufacture, labeling or packaging will be replaced, provided representative samples as well as batch numbers are returned to Impossible customer service. This warranty excludes all consequential damages. **Caution** This film uses a caustic paste. Do not cut or take apart the film. Avoid contact of the paste to skin, eyes or mouth. If you get paste on your skin, eyes or mouth, wipe it off immediately, wash with water to avoid an alkali burn and consult a doctor. Keep discarded materials and paste away from children, animals, clothing and furniture.

**Lagerung der Filme** Verwenden Sie die Filme innerhalb von 12 Monaten ab Produktionsdatum. Lagern Sie ungeöffnete Filme bei 5–10°C im Kühlschrank. Nicht im Gefrierfach aufbewahren! **Filmeigenschaften** Die Entwicklung dieses Films ist eine sensible, chemische Reaktion, ausgelöst von Licht und beeinflusst durch verschiedene Parameter wie Temperatur, Alter, Zeit, mechanische Manipulation und andere. Somit sind Variationen von Ergebnissen nicht nur möglich, sondern für diesen analogen Sofortbildfilm essentiell. **Gewährleistung** Jeder Film, der auf Grund von Herstellungs-, Kennzeichnungs- oder Verpackungsfehlern kein photographisches Ergebnis zeigt, wird ersetzt, sofern repräsentative Muster und eine Chargennummer an den Impossible Kundenservice geschickt werden können. Diese Garantie gilt nicht für Folgeschäden. **Vorsicht** Dieser Film beinhaltet ätzende Substanzen. Die Filme dürfen nicht zerschnitten oder auseinandergenommen werden. Vermeiden Sie Haut-, Augen- und Mundkontakt mit der Substanz. Sollten Sie dennoch damit in Kontakt kommen, bitte sofort abwischen und mit Wasser nachspülen um Verätzungen zu vermeiden, und suchen Sie einen Arzt auf. Halten Sie entsorgte Materialien und Substanzen von Kindern, Tieren, Kleidungs- und Möbelstücken fern.

**Conservation du film** Utilisation recommandée dans les 12 mois suivant la date de production. Stocker les packs fermés au réfrigérateur à 5–10°C. Ne pas congeler. **Caractéristiques du film** Le développement de ce film est dû à une réaction chimique, déclenchée par la lumière et réagissant à plusieurs paramètres tels que la température, l'âge, le temps de développement, la manipulation (entre autres). Ainsi, les variations de résultat ne sont pas seulement possibles mais font partie intégrante de ce film instantané. **Termes de la garantie limitée** Tout film ne présentant aucun résultat photographique à cause d'un défaut de fabrication, de marquage ou d'emballage sera remplacé, moyennant le renvoi d'échantillons défectueux ainsi que le numéro du lot à notre service clients. Cette garantie exclut tout autre type de dommage pouvant découler de ce problème. **Attention** Ce film contient des produits chimiques caustiques. Ne coupez pas le film ou ne séparez pas le film. Evitez tout contact de la chimie avec la peau, les yeux ou la bouche. Si votre peau, vos yeux ou votre bouche était en contact avec la chimie, essayez immédiatement et rincez abondamment avec de l'eau pour éviter toute brûlure et consultez un médecin sans tarder. Tenez tout composant ou chimie à l'écart des enfants, animaux, vêtements ou meubles.

Thank you for shooting Impossible 8x10 film. We invite you to share your instant photos with us in our online gallery

**Almacenamiento de la película** Recomendamos utilizar la película durante los 12 meses posteriores a su fecha de producción. Conserva la película sin abrir en el frigorífico a 5–10°C (41–50°F). No la congeles! **Características de la película** El revelado de esta película es una reacción química delicada, desencadenada por la luz y sobre la que influyen distintos parámetros como la temperatura, el envejecimiento, el tiempo y la manipulación mecánica, entre otros. En consecuencia, esta película instantánea analógica no sólo puede presentar variaciones en los resultados, sino que éstas son parte esencial de su naturaleza. **Garantía limitada** Cualquier película que no permita obtener ningún resultado fotográfico debido a defectos de fabricación, etiquetado o empaquetado será sustituida, siempre que se envíen muestras representativas y los números de lote al servicio de atención al cliente de Impossible. Esta garantía excluye todos los daños indirectos. **Advertencia** Esta película utiliza pasta cáustica y una batería. No corte ni rompa la película ni la batería. No queme la batería ni permita que sus terminales entren en contacto con metales. Evite todo contacto de la pasta con la piel, los ojos o la boca. Si la pasta entrase en contacto con la piel, los ojos o la boca, quítela inmediatamente, lave la parte afectada con agua para evitar posibles quemaduras alcalinas y consulte al médico. Mantenga los materiales desechados y la pasta cáustica alejados de los niños, animales, ropa o muebles.

「使用上及び保管上のご注意」製造日より1年以内にご使用いただけるよりよい状態での撮影ができます。使用前のフィルムは冷蔵庫などで(5°C–10°C)保管してください。ただしフィルムは冷凍しないでください。「フィルムの特徴」このフィルムは現像の際、撮影時の温度、エージング(製造されてから撮影されるまでの期間)、露光時間、マニピュレーションをはじめとする外圧等々によって影響を受けやすい化学反応を示します。よって、さまざまな現象結果が得られますが、逆にそうなりうると考慮して撮影してください。「保証について」製造上の原因による品質不良がございましたら、製造番号をご明記のうえ当該サンプルをImpossibleカスタマーサービスまでご返却ください。新しいフィルムとお取り替えいたします。フィルムの不良に起因するその他全ての損害は保証の対象外とさせていただきます。「注意」フィルムカートリッジには、苛性ペーストが内蔵されています。お子様や動物、衣服、家具などに近づかないでください。そして万一苛性ペーストが目や口に入った場合は、すぐに多量の水で洗い流し、医師の診療を受けてください。

儲存方法得到更好的結果，請生產日期後12個月內使用。請保持在5°C–10°C的冰箱電影底片特點 本底片的顯影效果會因光線以及溫度、底片新舊、曝光時間、機械操作或其他因素所產生的化學反應而有所不同。所以，每張即影即有相片的效果亦不盡相同。問題產品 如產品因製造、標籤或包裝失誤而未能顯現影像，客戶需向本公司的客戶服務部提交該問題底片的產品批號和樣本，方可獲得更換。本公司對問題底片可能所造成的損失恕不負責。注意事項 本底片採用腐蝕性物料和電池。切勿切斷、取出底片或電池、燃燒電池或觸及金屬。避免讓物料觸及皮膚、眼睛及口腔。如不慎觸及皮膚、眼睛或口腔，應立即將物料抹掉，並用清水沖洗及向醫生求助，以避免鹼性燒傷。請將棄置材料或腐蝕性物料遠離兒童、動物、衣物或家具。

필름 보관 주의사항 좋은 결과를 얻을 것은 생산 날짜 이후 12 개월 이내에 사용하시기 바랍니다. 5°C–10°C 에있는 냉장고에 필름을 보관하시기 바랍니다 필름의 특성 필름의 현상은 7영사의 온도, 노광 시간, 에이징(제조후 7영까지의 기간), 물리적 조작과 압력 등의 다양한 변수에 영향을 받으며 빛에 의하여 진행되는 섬세한 >학 반응의 결과입니다. 따라서 다양한 아날로그적인 결과물을 얻을 수 밖에 없습니다. 보증 제한 제조상의 결<으로 인한 7량의 경우에는 제조번호가 적힌 해당샘플을 모두 7파>를 고객센터원으로 보내주시기 바랍니다. 새로운 필름으로 교환하여 드립니다. 필름의 7량으로 기인한 부가적인 0>해는 보증하지 않습니다. 주의경고 이 필름은 수산> <<물과 건전지를 사용하고 있습니다. 필름 또는 건전지를 자르거나 분해하지 마세요. 필름이나 건전지를 7>에 넣거나 점점에 금>을 대지 마세요. 필름 안의 물질이 인체에 닿지 않도록 하세요. 혹시라도 묻으면 바로 흐르는 물로 씻고 의사와 상담하세요. 보관 또는 사용 후 버릴 때는 어린이, 동물, 의류, 가구 등과 멀리 하세요.

IMPOSSIBLE

10 good things to know before shooting Impossible 8x10 film



Thank you for this title photo, marshallyeti



1

## THE FILM IS NEW AND INTEGRAL

This film is a completely new invention consisting of a new negative, positive and developing agent. It is not Polaroid film and it is not a peel-apart film in the classic sense. This experimental integral film works with any 8x10 camera equipped to accept an 8x10 Polaroid film holder. Additionally, you will need a Polaroid 8x10 Processor. We recommend using an electrically powered processor for more consistent results, but there is also a hand crank function in case power is not available. If you use the hand crank, turn the handle quickly and smoothly.

2

## INTENDED FOR ASA 640, THOUGH THIS MAY VARY

The film is intended for ASA 640. Actual speed may vary from lot to lot. The film is suitable for daylight 5500K. Film sensitivity can vary in response to the color temperature of the light, and flash tends to slow the effective ASA. In direct sunlight, load holders in low light and do not pull off the protective envelope until you are ready to shoot.



3

## REFRIGERATE YOUR FILM UNTIL USE

This film is best stored cool in a refrigerator at 5–10°C/ 41–50°F. Do not freeze it! Take the film out of the refrigerator two hours before shooting to allow it to reach room temperature. The film works best when shot at temperatures between 12–28°C/55–82°F. At colder temperatures film sensitivity tends to increase. At hotter temperatures the tone of the film tends to get warmer and sensitivity decreases.

4

## KEEP YOUR PROCESSED IMAGE IN THE DARK

After processing, the photo will still be sensitive to light! Do not view your image immediately—keep the film in the dark processing compartment for four minutes. After four minutes, the photo can be removed and will be safe in light. The photo will continue to develop and clear over 24 hours.



5

## MOST IMPORTANT: DRY YOUR PHOTOS THOROUGHLY

A newly processed 8x10 photo consists of a layer of wet developing paste, sandwiched between a negative and a transparent sheet. In this “sealed” configuration, 8x10 photos can take 3–4 weeks to dry completely, and may change during this period. The faster the photo dries, the less the images will change.

### Two ways to stop further development and stabilize your images:

1. Peel the negative and transparent sheet apart to keep your photos truly black and white.
2. Use an Impossible 8x10 Dry Age Kit to speed the drying process. Minor shifts in tone during dry down are still possible.

### Regardless of which drying technique you choose:

- Do not stack the photos when they are wet or soft.
- Stand your prints vertically when drying.
- Maintain at least 1 cm of airspace around images when drying.
- If you need your images to dry more quickly, cut off the chemical strip at the end of the print.
- Dry down prints in a cool, dehumidified or air-conditioned space.
- Scan your photos for archiving purposes.



6

## KEEP THE PROCESSOR'S ROLLERS CLEAN

Check and clean your processor's rollers between every print. Any dirt or residue left on the rollers may cause an imprint on the image.

7

## BEAR IN MIND: IMAGES ARE MIRRORED

In most cases the images obtained with this film will be the mirror image of the original. For example, text will be reversed. If readable text is important to your image, we recommend trying the transparency or lifting techniques to revert the photo to its original orientation. Look for the 8x10 User Manual on our website.



8

## CAUTION: AVOID CONTACT WITH THE FILM PASTE

Some developing paste may seep from the edges of the photo. This paste is a caustic substance! Avoid contact with skin, eyes, or mouth. If you get paste on your skin, eyes or mouth, wipe it off immediately, flush with water to avoid an alkali burn and consult a doctor. Keep discarded materials and paste away from children, animals, clothing and furniture. You can easily avoid contact with the paste by holding the photo by the black tab and refraining from touching the edges. The paste can also be wiped off with a moist tissue.

9

## WE SUPPORT YOU

To learn all details on usage of 8x10 film and find all tutorials and updates please visit our website on [www.the-impossible-project.com/8x10](http://www.the-impossible-project.com/8x10). If you have any further questions, please visit our Online Support Desk at <http://support.the-impossible-project.com>



Thank you for these 8x10 photos, Melodie McDaniel, Chloe Aftel, Nicholas Misciagna, Bill Phelps, Stefan Milev and Rommel Pecson

10

## TECHNICAL SPECIFICATIONS

The new Impossible 8x10 Silver Shade Film is a high speed, medium contrast, monochrome integral film with a beautiful tonal range and experimental character and possibilities.

**Film speed:** Nominally ISO 640. Suitable for daylight 5500K. The ASA can vary in response to extreme temperatures outside of the range of 13–28°C (55–82°F) and to different color temperatures of light, with flash slowing down the effective ASA. In direct sunlight, load holders in low light and do not pull off the protective envelope until you are about to shoot.

**Exposures:** 10 exposures per box  
**Development time:** 4 minutes in the dark processing compartment with final development over approximately 25 minutes.

**Dimensions:** Format: 8x10 inches, image area: 7.5x9.35 inches/19x24 cm

**Finish:** glossy

**Dry down:** Peel Apart: 48 Hours, Dry Age: 3+ weeks  
Prints tend to dry down -2/3 stop darker, most noticeably in the mid to dark tones.

**Compatible hardware:** 8x10 Polaroid Processor and any 8x10 camera equipped to accept an 8x10 Polaroid film holder.

**Additional equipment needed:** Polaroid 8x10 Processor and film holders.