



## Loading instructions:

1. **Insert the Film:** Push the beginning of the film into the first groove of the reel until it holds in place.
2. **Start Winding:** Place your right index finger on the edge of the film to fix it. Turn the right reel half (flange) clockwise as far as it goes.



3. **Keep Winding:** Repeat the same on left flange.
4. **Repeat the Motion:** Keep rotating the left and right reel halves back and forth. This will draw the film smoothly into the spiral groove.

Thank you for choosing the  
Vintage Visual 110 reel.

Join our communities in Facebook & Discord and  
let us know how was your first developing experience.

[www.vintagevisual.eu](http://www.vintagevisual.eu) | [support@vintagevisual.eu](mailto:support@vintagevisual.eu)



Discord



Facebook



# REEL 110

## Chemical consumption:

Rotary agitation – same as Paterson reels

35mm tank	250ml
Universal tank	350ml
Multi-reel 3 tank	450ml
Multi-reel 5 tank	650ml
Multi-reel 8 tank	950ml

Vertical agitation – use a minimum of 175ml  
of chemical per reel