



ECN-2 PROCESSING FOR 8 ROLL KIT

WARNING: This kit contains chemicals that may be harmful if misused, keep out of the reach of children

Equipment required:

Timer, thermometer, processing tank or processor, 6 - 500ml chemical containers, graduate cylinder, microfiber cloth, water bath, gloves, mask and eye protection.

MIXING CHEMICALS:

Use distilled water for all mixing.

PLEASE NOTE, IF PREPARING FOR USE FOR TWO ROLLS OF 35MM IN A PATERSON TANK, MAKE 580ML OF SOLUTION. ALL OTHER USES USE 500ML.

PREBATH: Mix package into 400ml of water heated to 38 degrees (100F). Stir until dissolved, then fill to make 0.5 liter.

DEVELOPER: Mix package into 400ml of water heated to 45 degrees C (113F). Stir until dissolved, then fill to make 0.5 liter.

STOP BATH: Add water to make 0.5 litre

BLEACH: Mix package into 400ml of water heated to 38 degrees (100F). Stir until dissolved, then fill to make 0.5 liter.

FIXER: Add room temperature water to fixer to make 0.5 liter.

STABILIZER: Add to 0.5 liter of room temperature water.

DEVELOPING: Warm Prebath to 27C/80F. Warm Developer, Stop Bath, Bleach and Fixer to 41.1C/106F.

Each chemical can be re-used until the capacity of 8 rolls is reached.

PREBATH: Fill inversion tank (Paterson, AP) to capacity, tap sides to release bubbles and soak **10 seconds**, return prebath to container. Rinse three times, shaking vigorously each time. If using a Jobo

type processor, fill tank to “inversion” capacity and follow same instructions.

DEVELOPER: Fill tank, invert continuously for 10 seconds, then four inversions every 30 seconds until **3 minutes** have elapsed. (**3 minutes 40 seconds for 580ml**)

STOP BATH: Add stop bath, invert once and let stand for **30 seconds**.

RINSE: Exchange water three times.

BLEACH: Fill tank, invert continuously for 10 seconds, then four inversions every 30 seconds until **3 minutes** have elapsed. (**3 minutes 40 seconds for 580ml**)

RINSE: Exchange water three times.

FIXER: Fill tank, invert continuously for 10 seconds, then four inversions every 30 seconds until **2 minutes** have elapsed. (**2 minutes 30 seconds for 580ml**)

RINSE: Exchange water for **5 minutes**.

Take film off reel and wipe with a wet cloth to remove any remaining Remjet.

STABILIZER: Soak in stabilizer for **1 minute** at room temperature

Hang film to dry in a dust free location
Stopper all bottles and store at room temperature.